

# Key Chain Remote KC674

## INSTALLATION AND OPERATING INSTRUCTIONS

1. Open the battery compartment and use a small screwdriver to set the Housecode dial to match the X10 Modules and Transceiver you want to control.
2. Set the slide switch inside the battery compartment to control modules set to Unit Codes 1 and 2, OR 5 and 6 from the two buttons on the KC674.
3. Install 2 AAA alkaline batteries (sold separately) in the KC674's battery compartment. Observe polarity.
4. Plug in an X10 Transceiver (RR501 or TM751, sold separately).
6. Press the corresponding ON or OFF button to turn X10 Modules set to Unit Codes 1 and 2, OR 5 and 6 on and off. Button 1 (or 5) controls the Transceiver. Button 2 (or 6) transmits to the Transceiver which then retransmits to other X10 Modules (set to 2 or 6).

**F.C.C. CAUTION** - THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

**NOTE:** NO CHANGES OR MODIFICATIONS MAY BE MADE TO THE UNITS. ANY CHANGES MADE TO THE UNITS WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

---

### **X10 Wireless Technology, Inc. Limited One Year Warranty**

X10.com, a division of X10 Wireless Technology, Inc. (X10) warrants X10 products to be free from defective material and workmanship for a period of one (1) year from the original date of purchase at retail. X10 agrees to repair or replace, at its sole discretion, a defective X10 product if returned to X10 within the warranty period and with proof of purchase. If service is required under this warranty:

Call 1-800-442-5065, visit [www.x10.com](http://www.x10.com), or e-mail [support@x10.com](mailto:support@x10.com).

**For help or more information on setup, please visit:**

**<http://www.x10.com/support>**