


## Remote Chime, Model SC546A

### INSTALLATION AND OPERATING INSTRUCTIONS

1. Set the Housecode dial on the SC546A to the same letter as your X10 Controller (TM751, MS13A, MC460, etc.).
2. Set the Unit Code dial on the SC546A to any unused number between 1 & 16. If you are using it with a Motion Sensor, set it to the same Housecode and Unit Code as your Motion Sensor (MS13A/MS14A/MS16A) and the same Housecode as your Transceiver (TM751).
3. Plug the SC546A chime into any unused AC outlet (not one that is controlled by a wall switch, in case the switch accidentally gets turned off).
4. To test the SC546A, press the number button (on any X10 Controller) corresponding to the Unit Code you set on the SC546A. Or walk past a Motion Sensor. The Motion Sensor sends a signal to the TM751 which retransmits it over your house wiring to the SC546A. The SC546A then chimes.



trim

Check Out our Web site at:

<http://www.x10.com>

For more information on X10 products.

### X10 Wireless Technology, Inc. Limited One Year Warranty

X10.com, a division of X10 Wireless Technology, Inc. (X10) warrants X10 products to be free from defective material and workmanship for a period of one (1) year from the original date of purchase at retail. X10 agrees to repair or replace, at its sole discretion, a defective X10 product if returned to X10 within the warranty period and with proof of purchase. If service is required under this warranty:

Call 1-800-442-5065, visit [www.x10.com](http://www.x10.com), or e-mail [support@x10.com](mailto:support@x10.com).

For help or more information on setup, please visit:

<http://www.x10.com/support>